BCIT

COMP 7005 Final Project

December 2, 2014

Christopher Eng

A00842832

Project Introduction

The submitted COMP 7005 Final Project is a half-duplex TCP Reno-implemented Send-And-Wait protocol simulator. Using a C implementation, it is comprised of three components:

- Transmitter
- Receiver
- Network Emulator

A file transfer is performed from the transmitter to the receiver through the network emulator. The network emulator relays the data between the two end-points, while delaying and dropping packets to simulate an unreliable network.

Environment Setup

The program was developed for use on a Linux-based operating system. Each component contains the main source file, 3-4 header files, and a configuration file. Due to the use of timers, compilation requires linking with the real-time library.

Configuration File

The configuration file, <connections.cfg>, must be at least 7 lines long. The first line of the file is a descriptor on what the file contains. The second line onwards stores configurations on a line-by-line basis. Each line stores a key and its value, separated by whitespace. Given the nature of the project, the source files expect 6 keys:

- transmitter ip
- transmitter_port
- network_ip
- network_port
- receiver_ip
- receiver_port

Transmitter

Source files: <tcp clnt.c>, <config.h>, <connections.cfg>, <log.h>, <packet.h>, and <timer.h>.

Compilation using GCC: 'gcc tcp_clnt.c -o tcp_clnt -lrt'

Runtime: './tcp_clnt <filename>'

Parameters:

<filename> - The name of the file to send.

Receiver

Source files: <tcp_svr.c>, <config.h>, <connections.cfg>, <log.h>, <packet.h>, and <timer.h>.

Compilation using GCC: 'gcc tcp_svr.c -o tcp_svr -lrt'

Runtime: './tcp_svr <optional_window_size>'

Parameters:

<optional_window_size> - An optional argument indicating how many packets the receiver can store in
its buffer. Defaulted to 128 MSS.

Network Emulator

Source files: <tcp_network.c>, <config.h>, <connections.cfg>, <packet.h>, and <timer.h>.

Compilation using GCC: 'gcc tcp_network.c –o tcp_network -lrt'

Runtime: './tcp_network <bit_error_rate> <delay_usec>'

Parameters:

<bit_error_rate> - A floating-point value from 0 to 1 indicating what percentage of packets received to discard. 0 will operate the program in ideal conditions.

<delay_usec> - An integer indicating how many microseconds each packet should be held for before
relaying it to its proper destination.

Pseudo-Code

Transmitter

Read Filename parameter

Read Configuration File

Error if Configuration File is missing Network IP & Network Port

Error if file doesn't exist

Open connection to Network

Generate random initial SeqNum

Send SYN Packet to network

Start timer

Case	Timer expires	Receive SYN-ACK with expected SeqNum
Action	Resend SYN packet to network	Stop timer
Action	Start timer	Send ACK to network

Send filename to network

Start timer

Receive responses until a FIN packet response is read

Case	Timer expires	
Action	Resend first packet in window to network	
Action	Set SSThresh to half WindowSize,	
	WindowSize to 1,	
	Timer to twice its duration	
Action	Start timer	

Case	Receive packet with last ACKed SeqNum	
Action	Increment duplicate ACK count	
Condition	If duplicate ACK count = 3	
Action	Send first packet in window to network	
Action	Set SSthresh to half WindowSize,	
	WindowSize to half WindowSize + 3,	
	duplicate ACK count to 0	

Case	Receive packet with an ACK greater than last ACKed SeqNum	
Action	Stop timer	
Action	Set timer duration based on RTT	
Action	Remove ACKed packets from window	
Action	Double WindowSize if slow start (SSThresh > WindowSize)	
	Increment WindowSize if congestion avoidance (not slow start)	
Action	Read from file and load packet in window until window is full	
Action	Load 1-byte packets if receiver advertises an empty window	
Action	If entire file has been read and window has room, add FIN packet to window	
Action	Send all unsent packets in window to network	
Action	Start timer	

Send ACK packet for received FIN packet to network

Start timer

Case	Timer expires	Receive FIN packet
Action	Close connection	Stop timer
Action		Resend ACK packet to network
Action		Start timer

Receiver

Read Optional Window Size parameter

Read Configuration File

Error if Configuration File is missing Receiver Port

Listen for connections

Open connection

Receive SYN packet

Generate random initial SeqNum

Send SYN-ACK packet

Start timer

Case	Timer expires	Receive ACK with expected SeqNum or Data Packet with next expected SeqNum
Action	Resend SYN-ACK packet	Stop timer
Action	Start timer	If ACK, wait to receive Data Packet
Action		Set filename from Data Packet

Receive packets until a FIN packet has been received and ACKed

Case	Receive packet with expected SeqNum	
Action	Write data to file	
Action	Check buffer for any sequential packets stored and write data to file,	
	Remove packets from buffer	
Action	If timer is stopped, start timer	
	If timer is started, stop it and send ACK packet	

Case	Timer expires	
Action	Send ACK packet	

Case	Receive packet with SeqNum greater than expected SeqNum	
Action	Stop timer	
Action	Resend last ACKed packet	
Action	Add packet to buffer	

Ī	Case	Receive packet with SeqNum less than expected SeqNum	
	Action	Resend last ACKed packet	

Save file to Filename

Send FIN packet to network

Start timer

Case	Timer expires	Receive ACK packet with expected SeqNum
Action	Resend FIN packet	Stop timer
Action		Close connection

Network Emulator

Read Bit Error Rate and Delay parameters

Read Configuration File

Error if Configuration File is missing Network Port, Receiver IP, & Receiver Port

Listen for connections

Open connection to Transmitter

Open connection to Receiver

Loop until a connection closes

Case	Receive packet	
Action	Generate random number percentage	
Condition	If percentage is greater than Bit Error Rate	
Action	Add packet to end of list	
Action	Set packet timer value to remaining delay required before sending, minus all packet timer	
	values closer to front in list	
Action	If list only has 1 packet, start timer	

Case	Timer expires						
Action	Send packet to other end-point						
Action	Remove packet from beginning of list						
Action	Start timer with stored delay						

Implementation

Packets

Packets are implemented in the packet.h header file. The PacketType is an integer code that represents the different types of packets found in a TCP transmission. This is used for the 3-way handshake, data transmission, and closing the connection.

The SeqNum (Sequence Number) starts as a random number and increments by the number of bytes sent. A packet is identified by the first byte it is sending. To verify a packet has been sent, the receiver will send a packet containing an AckNum representing the next expected Sequence Number. This is calculated by adding the number of bytes in the received packet with its Sequence Number. The number of bytes can be found in the DataLength attribute. For the sake of simplicity, packets were designed to store 512 bytes of data storage even if this amount was not used. This is why the DataLength attribute was added. The data attribute is a character array that holds the actual packet payload.

Finally, the WindowSize is the size of the window for the sender. Since bytes are a set size in the emulator, this is represented by number of MSS packets (512 bytes). The transmitter must look at the WindowSize to ensure it is not overloading the receiver with more packets than can be stored. Since WindowSize is not in bytes, we cannot send smaller packets of data due to lack of data. However, when the receiver window is full, the transmitter sends 1-byte packets to ensure data is still sent, so the window will eventually clear up.

Window

The window acts as a linked list of packets, to represent a storage buffer for packets in a specific order. This is also implemented in the packet.h header file. WindowSegments hold a pointer to the next WindowSegment in the list. In the transmitter, we maintain pointers to the beginning and end of the linked list. This makes it easy to add packets to the end of the window and send packets from the beginning. The receiver buffer window is different, in that the window stores out-of-order packets that have larger sequence numbers than expected. Due to this, the receiver must maintain an ordered list. With each out-of-order packet received, it must iterate through the list and find the correct position to store the packet.

There is also a stored delay value and connection identifier, used only by the network emulator to know how long this packet has until it should be sent and which connection to send it through. The user sets a time period of delay per packet. Each packet that arrives should wait this amount of time before being sent to the other end-point. By utilizing a timer, we are able to set this timer and send the packet when a timeout occurs. For each packet that is received while the timer is running, we calculate how much time is left on the timer. The delay value for the packet is how much delay time is required to wait for the correct delay. For every sequential packet received, we subtract the delay time of the packets in front of it. When the first timer finishes, we load the timer with the next packet's delay time value and send it on timeout.

Timer

Timer calculations can be found in the timer.h header file. Global variables for estimatedRTT and devRTT are declared and used in this header file for the transmitter timer calculations. These variables allow the timer values to be weighted based on the actual round trip time for sending and receiving a packet. Initially, the estimated round trip time and deviation round trip time are both set to

250 msec. The initial timer value is 1 second based on the formula: estimatedRTT = estimatedRTT + 4*devRTT. The transmitter calculates the new estimated round trip time and deviation round trip time using the TCP calculations with the formulas: estimatedRTT = (1-a)*estimatedRTT + a*sampleRTT, where a = 0.125, and devRTT = (1-b)*devRTT + b*|sampleRTT - estimatedRTT|, where b = 0.25. sampleRTT is the new round trip time for the last sent packet. On a timeout, the transmitter doubles the timer value temporarily, to ensure the next packet sent makes it back.

Logger

The logger is utilized in both the transmitter and receiver modules. They are used to document error events that occur and the information of packets that are sent or received. The logger is setup to save information to the file <output.log>. Logger functions are on a line-by-line basis and prepend the timestamp in front of each line.

3-way Handshake

One unclear issue that arose during implementation was what happens when the receiver does not receive an ACK to its SYN-ACK packet, since a DATA packet can be sent by the transmitter immediately after without waiting for a response. Light research online was able to explain that if the receiver receives the transmitter's DATA packet, this implies that the 3-way handshake ACK was sent but not received. DATA packets have associated timers, which allow for retransmission if a response does not arrive. An identical issue was found when closing the connection.

Closing Connection

At the end of the program, the transmitter sends a FIN packet to signify it is finished sending and wants to close the connection. The receiver responds with an ACK to the FIN and sends its own FIN when it is finished ACKing any buffered packets in its window, signifying it is also ready to close its connection. The transmitter then ACKs this FIN packet and waits for a period of time before closing the connection, in case more packets arrive. In TCP, this is generally from 30 seconds to 2 minutes. For the purpose of simulation, this timer was implemented to utilize the standard timer value. If a FIN packet is received by the transmitter before the timer runs out, this indicates the ACK sent did not arrive and it is resent.

One unclear issue that arose during implementation was what happens when the transmitter does not receive an ACK to its FIN packet, since a FIN packet can be sent by the receiver immediately after without waiting for a response. Light research online was able to explain that if the transmitter receives the receiver's FIN packet, this implies that the ACK was sent but not received. If the receiver's FIN packet is not received, a timer on the receiving end allows for retransmission.

Receiver

The receiver acts as depicted by the receiver pseudo-code. One TCP feature implemented is the use of a timer. The timer value is set to 500 microseconds and represents the receiver waiting for

additional sequential packets to come before ACKing one. In TCP, the receiver will wait 500 microseconds for another incoming packet to ACK both at the same time. This will only occur once, so the ACK is sent if either the timeout occurs or if a new packet arrives while the timer is running. At this point, the new packet is also ACKed and the timer is stopped so that the ACK is not delayed beyond approving 2 packets.

Test Document

The following general program features will not be documented, as they were tested during development and are unrelated to the TCP protocols:

- Valid arguments
- File Existing
- Logging
- Configuration file
- Socket networking (Connecting, sending, receiving, polling)
- Timer (Initializing, handling timeout, setting, getting)
- Bit Error Rate
- Network Delay

Transmitter Sliding Window

The following table depicts the screenshot data by each round trip. Each row describes the sliding window by displaying which packets were sent and ACKed, how many packets remain unACKed in the window, how large the window is, and how many packets forward the window slid this round trip. The data is during TCP Slow Start, so the WindowSize is increasing while the window slides. Sequence numbers are depicted by the last 4 digits. This screenshot was taken of the transmitter's console log for an ideal TCP transmission, without any dropped packets or network delay.

SEND/RCV Type	SeqNum	AckNum	Length	Phase	Window	# UnACKed Timeout Interval
SEND SYN	•	•		3WAY HS	1	1 1s Onsec
Timer value changed	from 1 s, 0 i	nsec to 1 s,	189197508	nsec		
RCV SYN-ACK	579864929	157100493	1	3WAY HS	128	0 1s 189197508nsec
SEND ACK	157100493	579864930	1	3WAY HS	1	1 1s 189197508nsec
SEND DATA	157100494	1	10	SLOW ST	1	1 1s 189197508nsec
RCV ACK	1	157100493	1		128	0 1s 189197508nsec
Timer value changed	from 1 s, 189	9197508 nsec	to 1 s, 69	9329695 ns	ec	
SEND DATA	157100504	1	512	SLOW ST	2	2 1s 69329695nsec
RCV ACK	1	157101016	1		128	0 1s 69329695nsec
Timer value changed	from 1 s, 69	329695 nsec t	o 0 s, 99	1332390 ns	ec	
SEND DATA	157101016	1	512	SLOW ST	4	1 0s 991332390nsec
SEND DATA	157101528	1	512	SLOW ST	4	2 0s 991332390nsec
SEND DATA	157102040	1	512	SLOW ST	4	3 0s 991332390nsec
SEND DATA	157102552	1	512	SLOW ST	4	4 0s 991332390nsec
RCV ACK	1	157101528	1		128	0 0s 991332390nsec
Timer value changed	from 0 s, 99	332390 nsec	to 0 s, 9	32407904 n	sec	
SEND DATA	157103064	1	512	SLOW ST	8	4 0s 932407904nsec
SEND DATA	157103576	1	512	SLOW ST	8	5 0s 932407904nsec
SEND DATA	157104088	1	512	SLOW ST	8	6 0s 932407904nsec
SEND DATA	157104600	1	512	SLOW ST	8	7 0s 932407904nsec
SEND DATA	157105112	1	512	SLOW ST	8	8 0s 932407904nsec
RCV ACK	1	157102040	1		128	0 0s 932407904nsec
Timer value changed	from 0 s, 93	2407904 nsec	to 0 s, 80	55441080 n	sec	
SEND DATA	157105624	1	512	SLOW ST	16	8 0s 865441080nsec
SEND DATA	157106136	1	512	SLOW ST	16	9 0s 865441080nsec

SeqNums Sent	SeqNums ACKed	# UnACKed Pkts	WindowSize	Window Slide Amt
0494, 0504	0494, 0504	0	2	2
1016, 1528, 2040,	1016	3	4	1
2552				
3064, 3576, 4088,	1528	7	8	1
4600, 5112				

We notice the sequence numbers added each RTT fill up the open spaces in the window.

Slow Start Phase

TCP Slow Start can be tested by watching the WindowSize double each round trip. The phase column in the console log shows "SLOW ST" when this phase is active. This screenshot was taken of the transmitter's console log for an ideal TCP transmission, without any dropped packets or network delay.

SEND/RCV	Туре	SeqNum	AckNum	Length	Phase	Window	# UnACKed	Timeout Interval
SEND	SYN	157100492	0	1	3WAY HS	1	1	1s Onsec
Timer valu	ie changed	from 1 s, 0 m	nsec to 1 s,	189197508	nsec			
RCV	SYN-ACK	579864929	157100493	1	3WAY HS	128	0	1s 189197508nsec
SEND	ACK	157100493	579864930	1	3WAY HS	1 1	1	1s 189197508nsec
SEND	DATA	157100494	1	10	SLOW ST	1	1	1s 189197508nsec
RCV	ACK	1	157100493	1		128	0	1s 189197508nsec
Timer valu	ıe changed	from 1 s, 189	9197508 nsec	to 1 s, 69	9 <mark>329695 ns</mark>			
SEND	DATA	157100504	1	512	SLOW ST	2	2	1s 69329695nsec
RCV	ACK	1	157101016	1		128	0	1s 69329695nsec
Timer valu	ie changed	from 1 s, 693	329695 nsec t	o 0 s, 991	1 <mark>3</mark> 32390 ns	ec		
SEND	DATA	157101016	1	512	SLOW ST	4	1	0s 991332390nsec
SEND	DATA	157101528	1	512	SLOW ST	4	2	0s 991332390nsec
SEND	DATA	157102040	1	512	SLOW ST	4	3	0s 991332390nsec
SEND	DATA	157102552	1	512	SLOW ST	4	4	0s 991332390nsec
RCV	ACK	1	157101528	1		128	0	0s 991332390nsec
Timer valu	ie changed	from 0 s, 993	1332390 nsec	to 0 s, 93	3 <mark>2407904 n</mark>			
SEND	DATA	157103064	1	512	SLOW ST	8	4	0s 932407904nsec
SEND	DATA	157103576	1	512	SLOW ST	8	5	0s 932407904nsec
SEND	DATA	157104088	1	512	SLOW ST	8	6	0s 932407904nsec
SEND	DATA	157104600	1	512	SLOW ST	8	7	0s 932407904nsec
SEND	DATA	157105112	1	512	SLOW ST	8	8	0s 932407904nsec
RCV	ACK	1	157102040	1		128	0	0s 932407904nsec
Timer valu	ie changed	from 0 s, 932	2407904 nsec	to 0 s, 80	5 <mark>5441080 n</mark>	sec		
SEND	DATA	157105624	1	512	SLOW ST	16	8	0s 865441080nsec
SEND	DATA	157106136	1	512	SLOW ST	16	9	0s 865441080nsec

Congestion Avoidance Phase

TCP Congestion Avoidance phase begins when the window size grows larger than the slow start threshold. The slow start threshold is set on a packet loss. In the screenshot, fast retransmit causes the ssthresh to become half of the WindowSize 4 to become 2. The new WindowSize 5 is larger than 2, so the next send begins in congestion avoidance. The phase is set to "CONG AV" when congestion avoidance is active. We notice the WindowSize is incrementing with each round trip time. This screenshot was taken of the transmitter's console log for a TCP transmission with a 5% rate of dropped packets and no network delay.

SEND	DATA	144427567	1	512	SLOW ST	4	0 0s 542347393nsec
SEND	DATA	144428079	1	512	SLOW ST	4	1 0s 542347393nsec
SEND	DATA	144428591	1	512	SLOW ST	4	2 0s 542347393nsec
SEND	DATA	144429103	1	512	SLOW ST	4	3 0s 542347393nsec
RCV	ACK	1	144427567	1		126	0 0s 542347393nsec
3 Duplicat	e ACKs: Fa	ast Retransmit	t				
SEND	DATA	144427567	1	512	SLOW ST	5	3 0s 542347393nsec
RCV	ACK	1	144429103	1		128	0 0s 542347393nsec
Timer valu	ie changed	from 0 s, 542	2347393 nsec	to 0 s, 49	92829247 ns	sec	
SEND	DATA	144429103	1	512	CONG AV	6	1 0s 492829247nsec
SEND	DATA	144429615	1	512	CONG AV	6	2 0s 492829247nsec
SEND	DATA	144430127	1	512	CONG AV	6	3 0s 492829247nsec
SEND	DATA	144430639	1	512	CONG AV	6	4 0s 492829247nsec
SEND	DATA	144431151	1	512	CONG AV	6	5 0s 492829247nsec
SEND	DATA	144431663	1	512	CONG AV	6	6 0s 492829247nsec
RCV	ACK	1	144429103	1		128	0 0s 492829247nsec
RCV	ACK	1	144429615	1		128	0 0s 492829247nsec
Timer valu	ie changed	from 0 s, 492	2829247 nsec	to 0 s, 48	8 <mark>4593367 ns</mark>	sec	
SEND	DATA	144432175	1	512	CONG AV	7	6 0s 484593367nsec
SEND	DATA	144432687	1	512	CONG AV	7	7 0s 484593367nsec
RCV	ACK	1	144429615	1		128	0 0s 484593367nsec
RCV	ACK	1	144429615	1		128	0 0s 484593367nsec

Receiver Window

The receiver window can limit the transmitter's rate of sending by running out of space. When the receiver buffers packets to fill the entire receiver window, it advertises a WindowSize 0 to the transmitter. The transmitter has no choice but to send packets with a DataLength of 1 to keep the data sending so ACKs continue to flow, but not overload the receiver. This screenshot was taken of the receiver's console log for a TCP transmission, with a 10% rate of dropped packets and 100 usec network delay. The receiver window was initialized to 1 MSS large.

RCV	ACK	1 1254	16154	1	1	0 0s 308740619nsec
3 Duplicate	ACKs: Fast R	letransmit				
SEND	DATA 12	5416154	1	512 SLOW ST	6	6 0s 308740619nsec
RCV	ACK	1 1254	16154	1	0	0 0s 308740619nsec
RCV	ACK	1 1254	16154	1	0	0 0s 308740619nsec
RCV	ACK	1 1254	16666	1	0	0 0s 308740619nsec
Timer value	changed from	o s, 308740619	nsec to	0 s, 306770673 nsec		
Receiver Win	ndow Is Limit	ing Data Sent				
Receiver Win	ndow Is Limit	ing Data Sent		_		
SEND	DATA 12	5419226	1	1 CONG AV	7	6 0s 306770673nsec
SEND	DATA 12	5419227	1	1 CONG AV	7	7 0s 306770673nsec

Receiver Out-of-order Packets

Proof that the receiver can handle out-of-order packets is done by showing that the packets are buffered. In the screenshot, we notice that even though the receiver is receiving packets, the sequence numbers are greater than what it is expecting. These packets are being buffered in the receiver window, shown by a decrementing WindowSize from 128. When the transmitter finally sends the missing packet, the receiver can ACK all buffered packets. This screenshot was taken of the receiver's console log for a TCP transmission, with a 10% rate of dropped packets and 100 usec network delay.

SEND I	ACK I	1	1846867352	1		128 I	0 0s 500000nsec				
RCV	DATA	1846867864	1	512		8	0 0s 500000nsec				
SEND	ACK	1	1846867352	1		128	0 0s 500000nsec				
RCV	DATA	1846868376	1	512		8 j	1 0s 500000nsec				
SEND	ACK	1	1846867352	1		127	1 0s 500000nsec				
RCV	DATA	1846868888	1	512		9	2 0s 500000nsec				
SEND	ACK	1	1846867352	1		126	2 0s 500000nsec				
RCV	EOT	1846869400	1	467		9	3 0s 500000nsec				
SEND	ACK	1	1846867352	1		125	3 0s 500000nsec				
RCV	FIN	1846869867	1	1		9	4 0s 500000nsec				
SEND	ACK	1	1846867352	1		124	4 0s 500000nsec				
RCV	DATA	1846867352	1	512		8	5 0s 500000nsec				
Started 500	Started 500 usec timer before sen <mark>ding ACK</mark>										
Finished red	ceiving t	tcp_clnt.c									
SEND	ACK	1	1846869868	1		128	0 0s 500000nsec				

Receiver Waiting 500 Microseconds for Packets

Upon receiving DATA, the receiver should start a 500 usec timer to possibly receive a sequential DATA packet. The receiver ACKs the initial packet along with the new packet. If another packet is received, it should be ACKed immediately. If no packet is received, after the 500 usec is up, the initial packet is ACKed. This is tested by noticing the 500 usec timer starting in the receiver's console log. We notice that the ACK applies to both DATA packets received. This screenshot was taken of the receiver's console log for an ideal TCP transmission, without any dropped packets or network delay.

RCV	DATA	1669325117	1	512		32	0	0s 500000nsec
Started 500	usec tir	er before ser	nding ACK					
RCV	DATA	1669325629	1	512		32	0	0s 500000nsec
SEND	ACK	1	1669326141	1		128	0	0s 500000nsec
RCV	DATA	1669326141	1	512		32	0	0s 500000nsec
Started 500	usec tir	er before ser	nding ACK					
RCV	DATA	1669326653	1	512		32	0	0s 500000nsec
SEND	ACK	1	1669327165	1		128	0	0s 500000nsec

Fast Retransmit

Fast Retransmission is performed when the transmitter received 3 duplicate ACKs for the same sequence number. At this point, the transmitter will send the expected sequence number immediately and half the WindowSize + 3. The screenshot shows this happening, as well as a message printing to the console indicating a triple duplicate ACK event. This screenshot was taken of the transmitter's console log for a TCP transmission with a 5% rate of dropped packets and no network delay.

SEND	FIN 15	75933885	1	1 SLOW ST	64	34 0s 7	39119185nsec
RCV	ACK	1 1575	917034	1	128	0 0s 7	39119185nsec
RCV	ACK	1 1575	917034	1	127	0 0s 7	39119185nsec
RCV	ACK	1 1575	917034	1	126	0 0s 7	39119185nsec
3 Duplicate	ACKs: Fast	Retransmit					
SEND	DATA 15	75917034	1	512 SLOW ST	35	34 0s 7	39119185nsec

Transmitter Timeout

Transmitter Timeout occurs when none of the packets sent are ACKed in a round trip time. When this happens, the transmission's timer will expire and display a "Timeout: Retransmit". At this point, the first unACKed packet is resent and the WindowSize is reset to 1. This screenshot was taken of the transmitter's console log for a TCP transmission with a 5% rate of dropped packets and 100 usec of network delay.

SEND	DATA	144428591	1	512 CONG AV	7	7 0s 622967146nsec
RCV	ACK	1 :	144425519	1	125	0 0s 622967146nsec
Timer value	changed t	from 0 s, 62296	7146 nsec to 1	l s, 245934292 nsec		
Timeout: Re	transmit					
SEND	DATA	144425519	1	512 SLOW ST	1	1 1s 245934292nsec

Transmitter Timer Calculations

Transmitter Timer Calculations were verified to be correct during development through unit testing. These calculations are performed during runtime when the transmitter completes a round trip time cycle. This means that a packet is sent and a new ACK is returned without a timeout occurring. This event is not logged in output.log, but is printed to the console. Some of these messages are highlighted in the following screenshot. This screenshot was taken of the transmitter's console log for an ideal TCP transmission, without any dropped packets or network delay.

SEND/RCV	Туре	SeqNum	AckNum	Length	Phase	Window	# UnACKed	Timeout Interval
SEND	SYN	157100492	0	1	3WAY HS	1	1	1s Onsec
Timer valu	ie changed	from 1 s, 0 r	nsec to 1 s,	189197508	nsec			, û
RCV	SYN-ACK	579864929	157100493	1	3WAY HS	128	0	1s 189197508nsec
SEND	ACK	157100493	579864930	1	3WAY HS	1	1	1s 189197508nsec
SEND	DATA	157100494	1	10	SLOW ST	1	1	1s 189197508nsec
RCV	ACK	1	157100493	1		128	0	1s 189197508nsec
Timer valı	ie changed	from 1 s, 189	9197508 nsec	to 1 s, 6	9329695 nse	ec		Φ
SEND	DATA	157100504	1	512	SLOW ST	2	2	1s 69329695nsec
RCV	ACK	1	157101016	1		128	0	1s 69329695nsec
Timer valı	ie changed	from 1 s, 693	329695 nsec t	o 0 s, 99:	1332390 nse	ec		Φ
SEND	DATA	157101016	1	512	SLOW ST	4	1	0s 991332390nsec
SEND	DATA	157101528	1	512	SLOW ST	4	2	0s 991332390nsec
SEND	DATA	157102040	1	512	SLOW ST	4	3	0s 991332390nsec
SEND	DATA	157102552	1	512	SLOW ST	4	4	0s 991332390nsec
RCV	ACK	1	157101528	1		128	0	0s 991332390nsec
Timer valu	ie changed	from 0 s, 991	1332390 nsec	to 0 s, 9	32407904 ns	sec		Ω
SEND	DATA	157103064	1	512	SLOW ST	8	4	0s 932407904nsec
SEND	DATA	157103576	1	512	SLOW ST	8	5	0s 932407904nsec
SEND	DATA	157104088	1	512	SLOW ST	8	6	0s 932407904nsec
SEND	DATA	157104600	1	512	SLOW ST	8	7	0s 932407904nsec
SEND	DATA	157105112	1	512	SLOW ST	8	8	0s 932407904nsec
RCV	ACK	1	157102040	1		128	0	0s 932407904nsec
Timer valu	ie changed	from 0 s, 932	2407904 nsec	to 0 s, 8	65441080 ns	sec		₽
SEND	DATA	157105624	1	512	SLOW ST	16	8	0s 865441080nsec
SEND	DATA	157106136	1	512	SLOW ST	16	9	0s 865441080nsec

3-Way Handshake

TCP utilizes the 3-way handshake to initialize connections between a client and server. The 3-way handshake is implemented to send and receive the following sequence of PacketTypes: SYN, SYN-ACK, and ACK. This can be found in program screenshots with the defined phase "3WAY HS". These screenshot were taken of the console logs for an ideal TCP transmission, without any dropped packets or network delay.

Transmitter:

SEI	ND/RCV	Туре	SeqNum	AckNum	Length	Phase	Window #	# UnACKed Timeout Interval
	SEND	SYN	157100492	0	1	3WAY HS	1	1 1s Onsec
Tir	ner val	ue change	d from 1 s, 0	nsec to 1 s,	189197508	nsec		
	RCV	SYN-ACK	579864929	157100493	1	3WAY HS	128	0 1s 189197508nsec
	SEND	ACK	157100493	579864930	1	3WAY HS	1	1 1s 189197508nsec
	SEND	DATA	157100494	1	10	SLOW ST	1	1 1s 189197508nsec
	RCV	ACK	1	157100493	1 1		128	0 1s 189197508nsec


Receiver:

	SEND/RCV	I	Туре	I	SeqNum	I	AckNum	I	Length	I	Phase	2	I	Window	#Buffered	I	Timeout	Interval
Ì	RCV	Τ	SYN	T	157100492	Τ	0	T	1	Ī	3WAY	HS	ī	1	1	ī	2s Onsec	
	SEND	Ĺ	SYN-ACK	Ť	579864929	Ť	157100493	Ť	1	Ť	3WAY	HS	Ĺ	128	0	Ĺ	2s Onsed	:
	RCV	1	ACK	1	157100493	1	579864930	1	1	1	3WAY	HS	L	1	1	П	2s Onsed	=

Closing Connection

TCP closing connection protocol is completed using the FIN PacketType. The transmitter sends a FIN when it has finished sending all it needs to. Once the receiver responds to the FIN with an ACK, the receiver sends a FIN of its own meaning it also has finished sending all it needs to. This can be seen in the following screenshots through the PacketType combination, followed by the connection closing. These screenshot were taken of the console logs for an ideal TCP transmission, without any dropped packets or network delay.

Transmitter:



Receiver:

RCV	FIN :	1669335312	1	1		64	0 0s	500000nsec				
Started 500 usec timer before sending ACK												
Finished receiving tcp clnt.c												
SEND	ACK	1	1669335313	1		128	0 0s	500000nsec				
SEND	FIN	2089344551	1	1		128	0 2s	0nsec				
RCV	ACK	1	2089344552	1		1	0 2s	0nsec				
Connection	closed											

Known Bugs/Issues

- 1. A rare occurrence occurs with the transmitter where the program shuts down due to Segmentation Fault. There was not enough time to debug this issue, but it is known to appear with sequential timeouts in a row.
- 2. The EOT PacketType is not utilized as described in the project specifications. This does not seem to fit the TCP implementation, since the receiver does not need to know when a transmission has completed.
- 3. The network module delay argument was supposed to act as an average delay. Packets would be delayed by a dynamic amount based on standard deviation from the average, but instead the implemented delay is constant to the inputted parameter.
- 4. Timer timeout can cause duplicate printing to console. This is due to the asynchronous nature of the signal function that is run when a timeout occurs.